

APPLICATOR PARTS LIST				TYPE			AMP INCORPORATED HARRISBURG, PENNA.				
				SIDEWISE							
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA		TERMINALS	
1	WIRE CRIMPER 453933-7	1	453933-7	42	Shear Plate - Left	1	811855-1	TO APPLY TERMINAL		66113-	
2	INS. CRIMPER	1	465603-2	43	Shear Block - Right	1	386372	WIRE SIZE	CRIMP HEIGHT		
3	ANVIL	1	465998-1	44	Floating Shear	1	465406	26			
4	ANVIL SPACER	1	810070-4	45	Retaining Plate - Front	1	811714-3		237		
5	SHEAR BLADE			46	Retaining Plate - Rear	1	810822-1	22			
6	REAR SHEAR PLATE			47	Spring - Shear Return	1	374322				
7	REAR ANVIL SPACER Rear Plate	1	811959-1	48	Shear Depressor 453302-1	1	382265-7				
8	FRONT SHEAR PLATE			49	Key - Shear Retainer	1	386358	CRIMP	SIZE	TYPE	FEED
9	REAR ANVIL SPACER PLT.			50	Guard Mount	1	811986-1	WIRE	.062	"5"	
10	FRONT ANVIL SPACER BLOCK	1	810799-2	51	Punch Holder	1	810498-3	INSUL.	.070	"0"	.300
11	TOOL SPACER	1	370695	52	Punch ASSY.	1	810738-1	SLEEVED			
12	CRIMP SPACER	1	375548	53				INSULATION RANGE	WIRE RANGE		
13	FRONT STRIP GUIDE	1	810971-2	54				.053 Max.	26 - 22		
14	REAR STRIP GUIDE	1	465413-1	55				EXPLODED VIEW			
15	RAM	1	471912	56				A-6002-4 A-6002-6			
16	TOOL HOLDER			57				REMARKS:			
17	ADJ. CRIMP MOUNT ASSY.	1	465392-9	58				Max. Ins. Crimp Height .060			
18	ADJ. BLOCK			59				△ Mounts on top of item #13			
19	APPLICATOR MOUNT ASSY.			60							
20	BASE PLATE	1	465100	61							
21	BASE BLOCK	1	465101	62							
22	STRIP GUIDE PLATE	1	465414-1	63							
23	ANVIL HOLDER			64	Paper Separator	1	694927-1				
24	WIRE STOP	1	811787-1	65	TENSION ADJ. PLATE	1	374999				
25	STRIPPER - Wire Stop	1	386361	66	2 Ft. Dia. Reel Spind Assy.	1	453596-4				
26	STRIPPER MOUNT	1	386362	67	Air Feed Assy.	1	690021-				
27	RETAINER PLATE	1	389078	68	Lubricator Assy.	1	465181-2				
28	STRIPPER MOUNT BRACKET	1	387115-1	69	SYNTHETIC OIL	1	22014-1				
29	STRIPPER BUSHING	1	386368	70							
30	STOCK DRAG	1	386955	71							
31	STOCK DRAG HANDLE			72							
32	STOCK DRAG STUD	1	374900	REV. REVISION RECORD		DATE	BY	ECN			
33	STOCK DRAG SPRING	1	370572	B	Change Item 42 44 45	11-11-65					
34	STOCK DRAG ADJ. NUT	1	21022-3	C	ITEM 32 WAS -2	1/2/66					
35	FEED FINGER HOLDER	1	386912	D	ADD ITEM 38	12-20-66		L-4323			
36	FEED FINGER	1	386911	E	ITEM 7 WAS -2	5-8-69		L-6617			
37	FEED FINGER TIP	1	387251	F	ADDED ITEM 65 374999	5-27-69		L-6693			
38	FEED FINGER GUIDE	1	689915-2	G	REV. PER ECN	9-9-69		L-6952			
39	BASE CASTING	1	570238	H	REV PER ECN	6-4-71		L-8332			
40	GUARD 460881-2	1	460881-2	I	REV PER ECN	4/21/71		L-8362			
41	BRACKET	1	811304-1								

**— IMAGINE —
FOR REPLACEMENT**

■ DENOTES WEARING PARTS
RECOMMEND PURCHASE REPLACEMENT

THIS APPLICATOR IS TO BE USED ON
AMP-O-ELECTRIC 1-471273-2
AIR FEED

SERIAL NO.	DATE SHIPPED	DESIGNED
		6-21-65 R. Smith
CUSTOMER NAME AND ADDRESS		CHK'D L-21-65 K. Smith
		APP'D 5-1-66 C. Smith
APPLICATOR NUMBER	REV. M	670892-3
		SHEET 1 OF 31

CONTACT WIRE - FAS 2-17-77 RCB R1-78
M REV ITEM 40 11-10-78 LE/R R2752
K 48 WAS 378265-7-78 7-25-71 R2/R L-8399
L REV PER ECN 4-5-73 TK - L-9645
FOR HARDWARE SEE 1-687511-5